

---

---

**2004 CHEMICAL MONITORING SCHEDULE**

84 Lumber PWS

PWS ID: 2438012 **Sample Monitoring Point: EP001**

STU NAME: 84 Lumber STU ID: 2461530

Transient Noncommunity Ground Water

Effective Date: 1/1/04

---

---

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact Central District Office at (614) 728-3778 to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule.

**Chemicals**

**2004**

NITRATE	1 Sample between Jan 1 and Jun 30 Date Sample Taken: _____
NITRITE	1 Sample between Jan 1 and Jun 30 Date Sample Taken: _____

**NOTE: Check with your district office regarding your coliform monitoring requirements.**

**2004 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

PWS NAME: Bloomingburg, Village Of PWS TYPE: Community Ground Water

PWS ID: 2400012 **Sample Monitoring Point: EP001**

STU NAME: Bloomingburg PWS STU ID: 2454040

Effective Date: 1/1/04

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact Central District Office at (614) 728-3778 to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule.

**Chemicals** **2004** **Date Samples Taken**

Chemicals	2004	Date Samples Taken
INORGANICS	Not Required	
NITRATE	1 Sample between Jan 1 and Jun 30	
NITRITE	1 Sample between Jan 1 and Jun 30	
BROMATE	Not Required	
CHLORINE DIOXIDE	Not Required	
CHLORITE	Not Required	
VOLATILE ORGANIC CHEMICALS (VOC's)	Not Required	
SYNTHETIC ORGANIC CHEMICALS (SOC's)	Not Required	
RADIOLOGICALS	Alpha, total Radium-228	Not Required

\* A paired sample set refers to one source water and one treated water sample. A source water alkalinity is also required at the same time the TOC sample is taken.

---

---

**2004 CHEMICAL MONITORING DISTRIBUTION SCHEDULE**

PWS ID: 2400012 PWS Name: Bloomingburg, Village Of

Community Ground Water POPULATION: 950

Effective Date: 1/1/04

---

---

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district representative at Central District Office at (614) 728-3778 to review additional monitoring for total coliform, minimum requirements for chemical analysis for your monthly operating reports, and/or other monitoring requirements not included on this schedule.

**Chemicals****2004****Date Samples Taken**

Asbestos	1 sample between Jan 1 and Mar 31
Total Chlorine	Sample in the distribution system *
Haloacetic Acids (five) (HAA5)	1 Sample between Jul 1 and Sept 30
Total Trihalomethanes (TTHM)	1 Sample between Jul 1 and Sept 30
Chlorite	Not Required

**Disinfectants and Disinfection Byproducts Sampling Information**

Guidance on monitoring for the Disinfectants and Disinfection Byproducts rule and how to identify sampling locations and use of the Sample Monitoring Point Identifiers (SMPIDs) can be found in the "Ohio EPA Sample Monitoring Plan Template for Disinfectants and Disinfection Byproducts". An electronic version of the template is located at <http://www.epa.state.oh.us/ddagw/Documents/new-ddbp-smp3.PDF>. A copy of this document is also available from your local Ohio EPA District Office. Any questions concerning this schedule or the Disinfectants and Disinfection Byproducts Rule can be directed to Richard Ciotola of the Ohio EPA DDAGW Central Office at (614) 644-3387 or [richard.ciotola@epa.state.oh.us](mailto:richard.ciotola@epa.state.oh.us). Your district office representative is also available to provide assistance.

Multiple wells drawing water from a single aquifer may be considered one treatment plant for determining the number of TTHM and HAA5 samples required, with approval from Ohio EPA.

\* Total chlorine samples are collected in the distribution system at the same time and place as total coliforms are sampled.

\*\* One sample for Chlorite at each of the following locations: near the first customer, at a location representative of the average residence time, and at a location reflecting maximum residence time of the water in the distribution system.

**Asbestos Sampling Information**

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

---

---

**2004 CHEMICAL MONITORING SCHEDULE**

Buckeye Hills Country Cl

PWS ID: 2430612 **Sample Monitoring Point: EP001**

STU NAME: Buckeye Hills Country Club STU ID: 2454050

Transient Noncommunity Ground Water

Effective Date: 1/1/04

---

---

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact Central District Office at (614) 728-3778 to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule.

**Chemicals**

**2004**

NITRATE	1 Sample between Jan 1 and Jun 30 Date Sample Taken: _____
NITRITE	Not Required

**NOTE: Check with your district office regarding your coliform monitoring requirements.**

---

---

**2004 CHEMICAL MONITORING SCHEDULE**

Carter Lumber PWS

PWS ID: 2438312 **Sample Monitoring Point: EP001**

STU NAME: Carter Lumber STU ID: 2461567

Transient Noncommunity Ground Water

Effective Date: 1/1/04

---

---

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact Central District Office at (614) 728-3778 to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule.

**Chemicals**

**2004**

NITRATE	1 Sample between Jan 1 and Jun 30 Date Sample Taken: _____
NITRITE	1 Sample between Jan 1 and Jun 30 Date Sample Taken: _____

**NOTE: Check with your district office regarding your coliform monitoring requirements.**

---

---

**2004 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

PWS NAME: Chaffin Elementary Schoo PWS TYPE: Nontransient Noncommunity Ground Water

PWS ID: 2431212 **Sample Monitoring Point: EP001**

STU NAME: Chaffin Elementary School STU ID: 2454051

Effective Date: 1/1/04

---

---

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact Central District Office at (614) 728-3778 to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule.

**Chemicals** **2004** **Date Samples Taken**

Chemicals	2004	Date Samples Taken
INORGANICS	Not Required	
NITRATE	1 Sample between Jan 1 and Jun 30	
NITRITE	1 Sample between Jan 1 and Jun 30	
BROMATE	Not Required	
CHLORINE DIOXIDE	Not Required	
CHLORITE	Not Required	
VOLATILE ORGANIC CHEMICALS (VOC's)	Not Required	
SYNTHETIC ORGANIC CHEMICALS (SOC's)	Not Required	

\* A paired sample set refers to one source water and one treated water sample. A source water alkalinity is also required at the same time the TOC sample is taken.

**2004 CHEMICAL MONITORING DISTRIBUTION SCHEDULE**  
PWS ID: 2431212 PWS Name: Chaffin Elementary Schoo  
Nontransient Noncommunity Ground Water POPULATION: 142  
Effective Date: 1/1/04

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district representative at Central District Office at (614) 728-3778 to review additional monitoring for total coliform, minimum requirements for chemical analysis for your monthly operating reports, and/or other monitoring requirements not included on this schedule.

Chemicals	2004	Date Samples Taken
-----------	------	--------------------

Asbestos	Not Required	
Chlorite	Not Required	
Haloacetic Acids (five) (HAA5)	Not Required	
Total Trihalomethanes (TTHM)	Not Required	

**Disinfectants and Disinfection Byproducts Sampling Information**

Guidance on monitoring for the Disinfectants and Disinfection Byproducts rule and how to identify sampling locations and use of the Sample Monitoring Point Identifiers (SMPIDs) can be found in the "Ohio EPA Sample Monitoring Plan Template for Disinfectants and Disinfection Byproducts". An electronic version of the template is located at <http://www.epa.state.oh.us/ddagw/Documents/new-ddbp-smp3.PDF>. A copy of this document is also available from your local Ohio EPA District Office. Any questions concerning this schedule or the Disinfectants and Disinfection Byproducts Rule can be directed to Richard Ciotola of the Ohio EPA DDAGW Central Office at (614) 644-3387 or [richard.ciotola@epa.state.oh.us](mailto:richard.ciotola@epa.state.oh.us). Your district office representative is also available to provide assistance.

Multiple wells drawing water from a single aquifer may be considered one treatment plant for determining the number of TTHM and HAA5 samples required, with approval from Ohio EPA.

\* Total chlorine samples are collected in the distribution system at the same time and place as total coliforms are sampled.

\*\* One sample for Chlorite at each of the following locations: near the first customer, at a location representative of the average residence time, and at a location reflecting maximum residence time of the water in the distribution system.

**Asbestos Sampling Information**

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

**2004 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

PWS NAME: Eber Elementary School    PWS TYPE: Nontransient Noncommunity Ground Water

PWS ID: 2436612    **Sample Monitoring Point: EP001**

STU NAME: Eber Elementary School    STU ID: 2454068

Effective Date: 1/1/04

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact Central District Office at (614) 728-3778 to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule.

Chemicals	2004	Date Samples Taken
-----------	------	--------------------

INORGANICS	Not Required	
NITRATE	1 Sample quarterly Jan-Mar, Apr-Jun, Jul-Sep, Oct-Dec	
NITRITE	1 Sample between Jan 1 and Jun 30	
BROMATE	Not Required	
CHLORINE DIOXIDE	Not Required	
CHLORITE	Not Required	
VOLATILE ORGANIC CHEMICALS (VOC's)	Not Required	
SYNTHETIC ORGANIC CHEMICALS (SOC's)		
	2,4-Dichlorophenoxyacetic acid    1 Sample between Apr 1 and Jun 30 Benzo(a)pyrene Carbofuran Di(2-ethylhexyl)adipate Di(2-ethylhexyl)phthalate Diquat Endothall Glyphosate Lindane Methoxychlor Oxamyl Pentachlorophenol Picloram Polychlorinated biphenyls	

\* A paired sample set refers to one source water and one treated water sample. A source water alkalinity is also required at the same time the TOC sample is taken.

**2004 CHEMICAL MONITORING DISTRIBUTION SCHEDULE**

PWS ID: 2436612 PWS Name: Eber Elementary School  
Nontransient Noncommunity Ground Water POPULATION: 155  
Effective Date: 1/1/04

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district representative at Central District Office at (614) 728-3778 to review additional monitoring for total coliform, minimum requirements for chemical analysis for your monthly operating reports, and/or other monitoring requirements not included on this schedule.

**Chemicals** **2004** **Date Samples Taken**

Asbestos	Not Required
Chlorite	Not Required
Haloacetic Acids (five) (HAA5)	Not Required
Total Trihalomethanes (TTHM)	Not Required

**Disinfectants and Disinfection Byproducts Sampling Information**

Guidance on monitoring for the Disinfectants and Disinfection Byproducts rule and how to identify sampling locations and use of the Sample Monitoring Point Identifiers (SMPIDs) can be found in the "Ohio EPA Sample Monitoring Plan Template for Disinfectants and Disinfection Byproducts". An electronic version of the template is located at <http://www.epa.state.oh.us/ddagw/Documents/new-ddbp-smp3.PDF>. A copy of this document is also available from your local Ohio EPA District Office. Any questions concerning this schedule or the Disinfectants and Disinfection Byproducts Rule can be directed to Richard Ciotola of the Ohio EPA DDAGW Central Office at (614) 644-3387 or [richard.ciotola@epa.state.oh.us](mailto:richard.ciotola@epa.state.oh.us). Your district office representative is also available to provide assistance.

Multiple wells drawing water from a single aquifer may be considered one treatment plant for determining the number of TTHM and HAA5 samples required, with approval from Ohio EPA.

\* Total chlorine samples are collected in the distribution system at the same time and place as total coliforms are sampled.

\*\* One sample for Chlorite at each of the following locations: near the first customer, at a location representative of the average residence time, and at a location reflecting maximum residence time of the water in the distribution system.

**Asbestos Sampling Information**

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

---

---

**2004 CHEMICAL MONITORING SCHEDULE**

Farm Credit Services of Mid America PWS

PWS ID: 2437912 **Sample Monitoring Point: EP001**

STU NAME: Farm Credit Services of Mid America STU ID: 2461526

Transient Noncommunity Ground Water

Effective Date: 1/1/04

---

---

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact Central District Office at (614) 728-3778 to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule.

**Chemicals**

**2004**

NITRATE	1 Sample between Jan 1 and Jun 30 Date Sample Taken: _____
NITRITE	1 Sample between Jan 1 and Jun 30 Date Sample Taken: _____

**NOTE: Check with your district office regarding your coliform monitoring requirements.**

**2004 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

PWS NAME: Fayette Co.-Culpepper Su PWS TYPE: Community Ground Water

PWS ID: 2400112 **Sample Monitoring Point: EP001**

STU NAME: Fayette County Culpepper Subdivision STU ID: 2454041

Effective Date: 1/1/04

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact Central District Office at (614) 728-3778 to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule.

<b>Chemicals</b>	<b>2004</b>	<b>Date Samples Taken</b>
INORGANICS	Not Required	
NITRATE	1 Sample between Jan 1 and Jun 30	
NITRITE	1 Sample between Jan 1 and Jun 30	
BROMATE	Not Required	
CHLORINE DIOXIDE	Not Required	
CHLORITE	Not Required	
VOLATILE ORGANIC CHEMICALS (VOC's)	Not Required	
SYNTHETIC ORGANIC CHEMICALS (SOC's)	Not Required	
RADIOLOGICALS	Alpha, total Radium-228 Not Required	

\* A paired sample set refers to one source water and one treated water sample. A source water alkalinity is also required at the same time the TOC sample is taken.

---

---

**2004 CHEMICAL MONITORING DISTRIBUTION SCHEDULE**

PWS ID: 2400112 PWS Name: Fayette Co.-Culpepper Su

Community Ground Water POPULATION: 268

Effective Date: 1/1/04

---

---

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district representative at Central District Office at (614) 728-3778 to review additional monitoring for total coliform, minimum requirements for chemical analysis for your monthly operating reports, and/or other monitoring requirements not included on this schedule.

**Chemicals****2004****Date Samples Taken**

<b>Chemicals</b>	<b>2004</b>	<b>Date Samples Taken</b>
Total Chlorine	Sample in the distribution system *	
Haloacetic Acids (five) (HAA5)	1 Sample between Jul 1 and Sept 30	
Total Trihalomethanes (TTHM)	1 Sample between Jul 1 and Sept 30	
Asbestos	Not Required	
Chlorite	Not Required	

**Disinfectants and Disinfection Byproducts Sampling Information**

Guidance on monitoring for the Disinfectants and Disinfection Byproducts rule and how to identify sampling locations and use of the Sample Monitoring Point Identifiers (SMPIDs) can be found in the "Ohio EPA Sample Monitoring Plan Template for Disinfectants and Disinfection Byproducts". An electronic version of the template is located at <http://www.epa.state.oh.us/ddagw/Documents/new-ddbp-smp3.PDF>. A copy of this document is also available from your local Ohio EPA District Office. Any questions concerning this schedule or the Disinfectants and Disinfection Byproducts Rule can be directed to Richard Ciotola of the Ohio EPA DDAGW Central Office at (614) 644-3387 or [richard.ciotola@epa.state.oh.us](mailto:richard.ciotola@epa.state.oh.us). Your district office representative is also available to provide assistance.

Multiple wells drawing water from a single aquifer may be considered one treatment plant for determining the number of TTHM and HAA5 samples required, with approval from Ohio EPA.

\* Total chlorine samples are collected in the distribution system at the same time and place as total coliforms are sampled.

\*\* One sample for Chlorite at each of the following locations: near the first customer, at a location representative of the average residence time, and at a location reflecting maximum residence time of the water in the distribution system.

**Asbestos Sampling Information**

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

---

---

**2004 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

PWS NAME: Gusweiler's GM Center PWS TYPE: Nontransient Noncommunity Ground Water

PWS ID: 2437812 **Sample Monitoring Point: EP001**

STU NAME: Gusweiler's GM Center STU ID: 2461485

Effective Date: 1/1/04

---

---

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact Central District Office at (614) 728-3778 to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule.

<b>Chemicals</b>	<b>2004</b>	<b>Date Samples Taken</b>
INORGANICS	Not Required	
NITRATE	1 Sample between Jan 1 and Jun 30	
NITRITE	1 Sample between Jan 1 and Jun 30	
BROMATE	Not Required	
CHLORINE DIOXIDE	Not Required	
CHLORITE	Not Required	
VOLATILE ORGANIC CHEMICALS (VOC's)	Not Required	
SYNTHETIC ORGANIC CHEMICALS (SOC's)	Not Required	

\* A paired sample set refers to one source water and one treated water sample. A source water alkalinity is also required at the same time the TOC sample is taken.

**REVISED 2004 CHEMICAL MONITORING DISTRIBUTION SCHEDULE**

PWS ID: 2437812 PWS Name: Gusweiler's GM Center

Nontransient Noncommunity Ground Water POPULATION: 58

Effective Date: 3/1/04

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district representative at Central District Office at (614) 728-3778 to review additional monitoring for total coliform, minimum requirements for chemical analysis for your monthly operating reports, and/or other monitoring requirements not included on this schedule.

**Chemicals**

**2004**

**Date Samples Taken**

Asbestos	Not Required
Chlorite	Not Required
Haloacetic Acids (five) (HAA5)	Not Required
Total Trihalomethanes (TTHM)	Not Required

**Disinfectants and Disinfection Byproducts Sampling Information**

Guidance on monitoring for the Disinfectants and Disinfection Byproducts rule and how to identify sampling locations and use of the Sample Monitoring Point Identifiers (SMPIDs) can be found in the "Ohio EPA Sample Monitoring Plan Template for Disinfectants and Disinfection Byproducts". An electronic version of the template is located at <http://www.epa.state.oh.us/ddagw/Documents/new-ddbp-smp3.PDF>. A copy of this document is also available from your local Ohio EPA District Office. Any questions concerning this schedule or the Disinfectants and Disinfection Byproducts Rule can be directed to Richard Ciotola of the Ohio EPA DDAGW Central Office at (614) 644-3387 or [richard.ciotola@epa.state.oh.us](mailto:richard.ciotola@epa.state.oh.us). Your district office representative is also available to provide assistance.

Multiple wells drawing water from a single aquifer may be considered one treatment plant for determining the number of TTHM and HAA5 samples required, with approval from Ohio EPA.

\* Total chlorine samples are collected in the distribution system at the same time and place as total coliforms are sampled.

\*\* One sample for Chlorite at each of the following locations: near the first customer, at a location representative of the average residence time, and at a location reflecting maximum residence time of the water in the distribution system.

**Asbestos Sampling Information**

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

**Lead and Copper Monitoring Schedule**

Initial		
Sampling Period		Report is due to your district office no later than
Start	End	
1/1/04	6/30/04	7/10/04

System size (number of people served)	Number of sites (standard monitoring)
> 100,000	100
10,001 to 100,000	60
3,301 to 10,000	40
501 to 3,000	20
101 to 500	10
< 101	5

The dates and number of samples noted above supercede any previous schedule received from this agency. Copies of EPA Forms 5105, 5106, and 5107 are available on our web site at <http://www.epa.state.oh.us/ddagw/drinkforms.htm> or your district office to use for your next report. If your Lead and Copper monitoring does exceed an action level or if you have any other questions, please contact your district representative at Central District Office at (614) 728-3778

**2004 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

PWS NAME: Hillcrest Manor Nursing PWS TYPE: Community Ground Water

PWS ID: 2400312 **Sample Monitoring Point: EP001**

STU NAME: Hillcrest Manor Nursing Home STU ID: 2454042

Effective Date: 1/1/04

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact Central District Office at (614) 728-3778 to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule.

<b>Chemicals</b>	<b>2004</b>	<b>Date Samples Taken</b>
INORGANICS	Not Required	
NITRATE	1 Sample between Jan 1 and Jun 30	
NITRITE	1 Sample between Jan 1 and Jun 30	
BROMATE	Not Required	
CHLORINE DIOXIDE	Not Required	
CHLORITE	Not Required	
VOLATILE ORGANIC CHEMICALS (VOC's)	Not Required	
SYNTHETIC ORGANIC CHEMICALS (SOC's)	Not Required	
RADIOLOGICALS	Alpha, total Radium-228 Not Required	

\* A paired sample set refers to one source water and one treated water sample. A source water alkalinity is also required at the same time the TOC sample is taken.

---

---

**2004 CHEMICAL MONITORING DISTRIBUTION SCHEDULE**

PWS ID: 2400312 PWS Name: Hillcrest Manor Nursing

Community Ground Water POPULATION: 48

Effective Date: 1/1/04

---

---

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district representative at Central District Office at (614) 728-3778 to review additional monitoring for total coliform, minimum requirements for chemical analysis for your monthly operating reports, and/or other monitoring requirements not included on this schedule.

**Chemicals****2004****Date Samples Taken**

Total Chlorine	Sample in the distribution system *
Haloacetic Acids (five) (HAA5)	1 Sample between Jul 1 and Sept 30
Total Trihalomethanes (TTHM)	1 Sample between Jul 1 and Sept 30
Asbestos	Not Required
Chlorite	Not Required

**Disinfectants and Disinfection Byproducts Sampling Information**

Guidance on monitoring for the Disinfectants and Disinfection Byproducts rule and how to identify sampling locations and use of the Sample Monitoring Point Identifiers (SMPIDs) can be found in the "Ohio EPA Sample Monitoring Plan Template for Disinfectants and Disinfection Byproducts". An electronic version of the template is located at <http://www.epa.state.oh.us/ddagw/Documents/new-ddbp-smp3.PDF>. A copy of this document is also available from your local Ohio EPA District Office. Any questions concerning this schedule or the Disinfectants and Disinfection Byproducts Rule can be directed to Richard Ciotola of the Ohio EPA DDAGW Central Office at (614) 644-3387 or [richard.ciotola@epa.state.oh.us](mailto:richard.ciotola@epa.state.oh.us). Your district office representative is also available to provide assistance.

Multiple wells drawing water from a single aquifer may be considered one treatment plant for determining the number of TTHM and HAA5 samples required, with approval from Ohio EPA.

\* Total chlorine samples are collected in the distribution system at the same time and place as total coliforms are sampled.

\*\* One sample for Chlorite at each of the following locations: near the first customer, at a location representative of the average residence time, and at a location reflecting maximum residence time of the water in the distribution system.

**Asbestos Sampling Information**

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

**2004 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

PWS NAME: I-71 &amp; Sr-35 Water Syste PWS TYPE: Community Ground Water

PWS ID: 2437412 **Sample Monitoring Point: EP001**

STU NAME: I-71 &amp; St Rte 35 Water System STU ID: 2454071

Effective Date: 1/1/04

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact Central District Office at (614) 728-3778 to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule.

**Chemicals** **2004** **Date Samples Taken**

Chemicals	2004	Date Samples Taken
INORGANICS	Not Required	
NITRATE	1 Sample between Jan 1 and Jun 30	
NITRITE	1 Sample between Jan 1 and Jun 30	
BROMATE	Not Required	
CHLORINE DIOXIDE	Not Required	
CHLORITE	Not Required	
VOLATILE ORGANIC CHEMICALS (VOC's)	Not Required	
SYNTHETIC ORGANIC CHEMICALS (SOC's)	Not Required	
RADIOLOGICALS	Alpha, total Radium-228	Not Required

\* A paired sample set refers to one source water and one treated water sample. A source water alkalinity is also required at the same time the TOC sample is taken.

**2004 CHEMICAL MONITORING DISTRIBUTION SCHEDULE**

PWS ID: 2437412 PWS Name: I-71 & Sr-35 Water System

Community Ground Water POPULATION: 3340

Effective Date: 1/1/04

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district representative at Central District Office at (614) 728-3778 to review additional monitoring for total coliform, minimum requirements for chemical analysis for your monthly operating reports, and/or other monitoring requirements not included on this schedule.

Chemicals	2004	Date Samples Taken
-----------	------	--------------------

Total Chlorine	Sample in the distribution system *	
Haloacetic Acids (five) (HAA5)	1 Sample between Jul 1 and Sept 30	
Total Trihalomethanes (TTHM)	1 Sample between Jul 1 and Sept 30	
Asbestos	Not Required	
Chlorite	Not Required	

**Disinfectants and Disinfection Byproducts Sampling Information**

Guidance on monitoring for the Disinfectants and Disinfection Byproducts rule and how to identify sampling locations and use of the Sample Monitoring Point Identifiers (SMPIDs) can be found in the "Ohio EPA Sample Monitoring Plan Template for Disinfectants and Disinfection Byproducts". An electronic version of the template is located at <http://www.epa.state.oh.us/ddagw/Documents/new-ddbp-smp3.PDF>. A copy of this document is also available from your local Ohio EPA District Office. Any questions concerning this schedule or the Disinfectants and Disinfection Byproducts Rule can be directed to Richard Ciotola of the Ohio EPA DDAGW Central Office at (614) 644-3387 or [richard.ciotola@epa.state.oh.us](mailto:richard.ciotola@epa.state.oh.us). Your district office representative is also available to provide assistance.

Multiple wells drawing water from a single aquifer may be considered one treatment plant for determining the number of TTHM and HAA5 samples required, with approval from Ohio EPA.

\* Total chlorine samples are collected in the distribution system at the same time and place as total coliforms are sampled.

\*\* One sample for Chlorite at each of the following locations: near the first customer, at a location representative of the average residence time, and at a location reflecting maximum residence time of the water in the distribution system.

**Asbestos Sampling Information**

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

**Lead and Copper Monitoring Schedule**

Triennial		
Sampling Period		Report is due to your district office no later than
Start	End	
6/1/04	9/30/04	10/10/04

System size (number of people served)	Number of sites (reduced monitoring)
> 100,000	50
10,001 to 100,000	30
3,301 to 10,000	20
501 to 3,000	10
101 to 500	5
< 101	5

The dates and number of samples noted above supercede any previous schedule received from this agency. Copies of EPA Forms 5105, 5106, and 5107 are available on our web site at <http://www.epa.state.oh.us/ddagw/drinkforms.htm> or your district office to use for your next report. If your Lead and Copper monitoring does exceed an action level or if you have any other questions, please contact your district representative at Central District Office at (614) 728-3778

**2004 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

PWS NAME: Jeffersonville, Village PWS TYPE: Community Ground Water

PWS ID: 2400612 **Sample Monitoring Point: EP001**

STU NAME: Jeffersonville PWS STU ID: 2454044

Effective Date: 1/1/04

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact Central District Office at (614) 728-3778 to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule.

**Chemicals** **2004** **Date Samples Taken**

Chemicals	2004	Date Samples Taken
INORGANICS	Not Required	
NITRATE	1 Sample between Jan 1 and Jun 30	
NITRITE	1 Sample between Jan 1 and Jun 30	
BROMATE	Not Required	
CHLORINE DIOXIDE	Not Required	
CHLORITE	Not Required	
VOLATILE ORGANIC CHEMICALS (VOC's)	Not Required	
SYNTHETIC ORGANIC CHEMICALS (SOC's)	Not Required	
RADIOLOGICALS	Alpha, total Radium-228	Not Required

\* A paired sample set refers to one source water and one treated water sample. A source water alkalinity is also required at the same time the TOC sample is taken.

---

---

**2004 CHEMICAL MONITORING DISTRIBUTION SCHEDULE**

PWS ID: 2400612 PWS Name: Jeffersonville, Village

Community Ground Water POPULATION: 1280

Effective Date: 1/1/04

---

---

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district representative at Central District Office at (614) 728-3778 to review additional monitoring for total coliform, minimum requirements for chemical analysis for your monthly operating reports, and/or other monitoring requirements not included on this schedule.

**Chemicals****2004****Date Samples Taken**

Asbestos	1 sample between Jan 1 and Mar 31
Total Chlorine	Sample in the distribution system *
Haloacetic Acids (five) (HAA5)	1 Sample between Jul 1 and Sept 30
Total Trihalomethanes (TTHM)	1 Sample between Jul 1 and Sept 30
Chlorite	Not Required

**Disinfectants and Disinfection Byproducts Sampling Information**

Guidance on monitoring for the Disinfectants and Disinfection Byproducts rule and how to identify sampling locations and use of the Sample Monitoring Point Identifiers (SMPIDs) can be found in the "Ohio EPA Sample Monitoring Plan Template for Disinfectants and Disinfection Byproducts". An electronic version of the template is located at <http://www.epa.state.oh.us/ddagw/Documents/new-ddbp-smp3.PDF>. A copy of this document is also available from your local Ohio EPA District Office. Any questions concerning this schedule or the Disinfectants and Disinfection Byproducts Rule can be directed to Richard Ciotola of the Ohio EPA DDAGW Central Office at (614) 644-3387 or [richard.ciotola@epa.state.oh.us](mailto:richard.ciotola@epa.state.oh.us). Your district office representative is also available to provide assistance.

Multiple wells drawing water from a single aquifer may be considered one treatment plant for determining the number of TTHM and HAA5 samples required, with approval from Ohio EPA.

\* Total chlorine samples are collected in the distribution system at the same time and place as total coliforms are sampled.

\*\* One sample for Chlorite at each of the following locations: near the first customer, at a location representative of the average residence time, and at a location reflecting maximum residence time of the water in the distribution system.

**Asbestos Sampling Information**

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

**2004 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

PWS NAME: Madison Mills Elementary PWS TYPE: Nontransient Noncommunity Ground Water

PWS ID: 2433312 **Sample Monitoring Point: EP001**

STU NAME: Madison Mills School STU ID: 2454058

Effective Date: 1/1/04

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact Central District Office at (614) 728-3778 to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule.

**Chemicals** **2004** **Date Samples Taken**

Chemicals	2004	Date Samples Taken
INORGANICS	Not Required	
NITRATE	1 Sample between Jan 1 and Jun 30	
NITRITE	1 Sample between Jan 1 and Jun 30	
BROMATE	Not Required	
CHLORINE DIOXIDE	Not Required	
CHLORITE	Not Required	
VOLATILE ORGANIC CHEMICALS (VOC's)	Not Required	
SYNTHETIC ORGANIC CHEMICALS (SOC's)	Not Required	

\* A paired sample set refers to one source water and one treated water sample. A source water alkalinity is also required at the same time the TOC sample is taken.

**2004 CHEMICAL MONITORING DISTRIBUTION SCHEDULE**  
PWS ID: 2433312 PWS Name: Madison Mills Elementary  
Nontransient Noncommunity Ground Water POPULATION: 180  
Effective Date: 1/1/04

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district representative at Central District Office at (614) 728-3778 to review additional monitoring for total coliform, minimum requirements for chemical analysis for your monthly operating reports, and/or other monitoring requirements not included on this schedule.

Chemicals	2004	Date Samples Taken
-----------	------	--------------------

Asbestos	Not Required	
Chlorite	Not Required	
Haloacetic Acids (five) (HAA5)	Not Required	
Total Trihalomethanes (TTHM)	Not Required	

**Disinfectants and Disinfection Byproducts Sampling Information**

Guidance on monitoring for the Disinfectants and Disinfection Byproducts rule and how to identify sampling locations and use of the Sample Monitoring Point Identifiers (SMPIDs) can be found in the "Ohio EPA Sample Monitoring Plan Template for Disinfectants and Disinfection Byproducts". An electronic version of the template is located at <http://www.epa.state.oh.us/ddagw/Documents/new-ddbp-smp3.PDF>. A copy of this document is also available from your local Ohio EPA District Office. Any questions concerning this schedule or the Disinfectants and Disinfection Byproducts Rule can be directed to Richard Ciotola of the Ohio EPA DDAGW Central Office at (614) 644-3387 or [richard.ciotola@epa.state.oh.us](mailto:richard.ciotola@epa.state.oh.us). Your district office representative is also available to provide assistance.

Multiple wells drawing water from a single aquifer may be considered one treatment plant for determining the number of TTHM and HAA5 samples required, with approval from Ohio EPA.

\* Total chlorine samples are collected in the distribution system at the same time and place as total coliforms are sampled.

\*\* One sample for Chlorite at each of the following locations: near the first customer, at a location representative of the average residence time, and at a location reflecting maximum residence time of the water in the distribution system.

**Asbestos Sampling Information**

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

---

---

**2004 CHEMICAL MONITORING SCHEDULE**

Mayer Farm Equipment PWS

PWS ID: 2438112 **Sample Monitoring Point: EP001**

STU NAME: Mayer Farm Equipment STU ID: 2461531

Transient Noncommunity Ground Water

Effective Date: 1/1/04

---

---

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact Central District Office at (614) 728-3778 to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule.

**Chemicals**

**2004**

NITRATE	1 Sample between Jan 1 and Jun 30 Date Sample Taken: _____
NITRITE	1 Sample between Jan 1 and Jun 30 Date Sample Taken: _____

**NOTE: Check with your district office regarding your coliform monitoring requirements.**

---

---

**2004 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

PWS NAME: Miami Trace High School PWS TYPE: Nontransient Noncommunity Ground Water

PWS ID: 2436312 **Sample Monitoring Point: EP001**

STU NAME: Miami Trace High School STU ID: 2454067

Effective Date: 1/1/04

---

---

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact Central District Office at (614) 728-3778 to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule.

**Chemicals** **2004** **Date Samples Taken**

<b>Chemicals</b>	<b>2004</b>	<b>Date Samples Taken</b>
INORGANICS	Not Required	
NITRATE	1 Sample between Jan 1 and Jun 30	
NITRITE	1 Sample between Jan 1 and Jun 30	
BROMATE	Not Required	
CHLORINE DIOXIDE	Not Required	
CHLORITE	Not Required	
VOLATILE ORGANIC CHEMICALS (VOC's)	Not Required	
SYNTHETIC ORGANIC CHEMICALS (SOC's)	Not Required	

\* A paired sample set refers to one source water and one treated water sample. A source water alkalinity is also required at the same time the TOC sample is taken.

---

---

**2004 CHEMICAL MONITORING DISTRIBUTION SCHEDULE**

PWS ID: 2436312 PWS Name: Miami Trace High School

Nontransient Noncommunity Ground Water POPULATION: 892

Effective Date: 1/1/04

---

---

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district representative at Central District Office at (614) 728-3778 to review additional monitoring for total coliform, minimum requirements for chemical analysis for your monthly operating reports, and/or other monitoring requirements not included on this schedule.

**Chemicals****2004****Date Samples Taken**

Total Chlorine	Sample in the distribution system *
Haloacetic Acids (five) (HAA5)	1 Sample between Jul 1 and Sept 30
Total Trihalomethanes (TTHM)	1 Sample between Jul 1 and Sept 30
Asbestos	Not Required
Chlorite	Not Required

**Disinfectants and Disinfection Byproducts Sampling Information**

Guidance on monitoring for the Disinfectants and Disinfection Byproducts rule and how to identify sampling locations and use of the Sample Monitoring Point Identifiers (SMPIDs) can be found in the "Ohio EPA Sample Monitoring Plan Template for Disinfectants and Disinfection Byproducts". An electronic version of the template is located at <http://www.epa.state.oh.us/ddagw/Documents/new-ddbp-smp3.PDF>. A copy of this document is also available from your local Ohio EPA District Office. Any questions concerning this schedule or the Disinfectants and Disinfection Byproducts Rule can be directed to Richard Ciotola of the Ohio EPA DDAGW Central Office at (614) 644-3387 or [richard.ciotola@epa.state.oh.us](mailto:richard.ciotola@epa.state.oh.us). Your district office representative is also available to provide assistance.

Multiple wells drawing water from a single aquifer may be considered one treatment plant for determining the number of TTHM and HAA5 samples required, with approval from Ohio EPA.

\* Total chlorine samples are collected in the distribution system at the same time and place as total coliforms are sampled.

\*\* One sample for Chlorite at each of the following locations: near the first customer, at a location representative of the average residence time, and at a location reflecting maximum residence time of the water in the distribution system.

**Asbestos Sampling Information**

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

---

---

**2004 CHEMICAL MONITORING SCHEDULE**

Odot Rest Area 6-10 PWS

PWS ID: 2430112 **Sample Monitoring Point: EP001**

STU NAME: ODOT Rest Area 6-10 STU ID: 2454049

Transient Noncommunity Ground Water

Effective Date: 1/1/04

---

---

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact Central District Office at (614) 728-3778 to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule.

**Chemicals**

**2004**

NITRATE	1 Sample between Jan 1 and Jun 30 Date Sample Taken: _____
NITRITE	Not Required

**NOTE: Check with your district office regarding your coliform monitoring requirements.**

**2004 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

PWS NAME: Pine Tree Court Apartments 1 PWS PWS TYPE: Community Ground Water

PWS ID: 2401312 **Sample Monitoring Point: EP001**

STU NAME: Pine Tree Ct Apts 1 STU ID: 2454043

Effective Date: 1/1/04

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact Central District Office at (614) 728-3778 to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule.

**Chemicals** **2004** **Date Samples Taken**

<b>Chemicals</b>	<b>2004</b>	<b>Date Samples Taken</b>
INORGANICS	Not Required	
NITRATE	1 Sample between Jan 1 and Jun 30	
NITRITE	1 Sample between Jan 1 and Jun 30	
BROMATE	Not Required	
CHLORINE DIOXIDE	Not Required	
CHLORITE	Not Required	
VOLATILE ORGANIC CHEMICALS (VOC's)	Not Required	
SYNTHETIC ORGANIC CHEMICALS (SOC's)	Not Required	
RADIOLOGICALS	Alpha, total Radium-228	Not Required

\* A paired sample set refers to one source water and one treated water sample. A source water alkalinity is also required at the same time the TOC sample is taken.

**2004 CHEMICAL MONITORING DISTRIBUTION SCHEDULE**  
PWS ID: 2401312 PWS Name: Pine Tree Court Apartments 1 PWS  
Community Ground Water POPULATION: 72  
Effective Date: 1/1/04

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district representative at Central District Office at (614) 728-3778 to review additional monitoring for total coliform, minimum requirements for chemical analysis for your monthly operating reports, and/or other monitoring requirements not included on this schedule.

Chemicals	2004	Date Samples Taken
-----------	------	--------------------

Total Chlorine	Sample in the distribution system *	
Haloacetic Acids (five) (HAA5)	1 Sample between Jul 1 and Sept 30	
Total Trihalomethanes (TTHM)	1 Sample between Jul 1 and Sept 30	
Asbestos	Not Required	
Chlorite	Not Required	

**Disinfectants and Disinfection Byproducts Sampling Information**

Guidance on monitoring for the Disinfectants and Disinfection Byproducts rule and how to identify sampling locations and use of the Sample Monitoring Point Identifiers (SMPIDs) can be found in the "Ohio EPA Sample Monitoring Plan Template for Disinfectants and Disinfection Byproducts". An electronic version of the template is located at <http://www.epa.state.oh.us/ddagw/Documents/new-ddbp-smp3.PDF>. A copy of this document is also available from your local Ohio EPA District Office. Any questions concerning this schedule or the Disinfectants and Disinfection Byproducts Rule can be directed to Richard Ciotola of the Ohio EPA DDAGW Central Office at (614) 644-3387 or [richard.ciotola@epa.state.oh.us](mailto:richard.ciotola@epa.state.oh.us). Your district office representative is also available to provide assistance.

Multiple wells drawing water from a single aquifer may be considered one treatment plant for determining the number of TTHM and HAA5 samples required, with approval from Ohio EPA.

\* Total chlorine samples are collected in the distribution system at the same time and place as total coliforms are sampled.

\*\* One sample for Chlorite at each of the following locations: near the first customer, at a location representative of the average residence time, and at a location reflecting maximum residence time of the water in the distribution system.

**Asbestos Sampling Information**

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

## Lead and Copper Monitoring Schedule

Triennial		
Sampling Period		Report is due to your district office no later than
Start	End	
6/1/04	9/30/04	10/10/04

System size (number of people served)	Number of sites (reduced monitoring)
> 100,000	50
10,001 to 100,000	30
3,301 to 10,000	20
501 to 3,000	10
101 to 500	5
< 101	5

The dates and number of samples noted above supercede any previous schedule received from this agency. Copies of EPA Forms 5105, 5106, and 5107 are available on our web site at <http://www.epa.state.oh.us/ddagw/drinkforms.htm> or your district office to use for your next report. If your Lead and Copper monitoring does exceed an action level or if you have any other questions, please contact your district representative at Central District Office at (614) 728-3778

**2004 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

PWS NAME: Pine Tree Court Apartments 3 PWS PWS TYPE: Community Ground Water

PWS ID: 2401212 **Sample Monitoring Point: EP002**

STU NAME: Pine Tree Court Apartments 3 STU ID: 2454047

Effective Date: 1/1/04

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact Central District Office at (614) 728-3778 to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule.

**Chemicals** **2004** **Date Samples Taken**

Chemicals	2004	Date Samples Taken
INORGANICS	Not Required	
NITRATE	1 Sample between Jan 1 and Jun 30	
NITRITE	1 Sample between Jan 1 and Jun 30	
BROMATE	Not Required	
CHLORINE DIOXIDE	Not Required	
CHLORITE	Not Required	
VOLATILE ORGANIC CHEMICALS (VOC's)	Not Required	
SYNTHETIC ORGANIC CHEMICALS (SOC's)	Not Required	
RADIOLOGICALS	Alpha, total Radium-228	Not Required

\* A paired sample set refers to one source water and one treated water sample. A source water alkalinity is also required at the same time the TOC sample is taken.

**2004 CHEMICAL MONITORING DISTRIBUTION SCHEDULE**  
PWS ID: 2401212 PWS Name: Pine Tree Court Apartments 3 PWS  
Community Ground Water POPULATION: 14  
Effective Date: 1/1/04

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district representative at Central District Office at (614) 728-3778 to review additional monitoring for total coliform, minimum requirements for chemical analysis for your monthly operating reports, and/or other monitoring requirements not included on this schedule.

Chemicals	2004	Date Samples Taken
-----------	------	--------------------

Total Chlorine	Sample in the distribution system *	
Haloacetic Acids (five) (HAA5)	1 Sample between Jul 1 and Sept 30	
Total Trihalomethanes (TTHM)	1 Sample between Jul 1 and Sept 30	
Asbestos	Not Required	
Chlorite	Not Required	

**Disinfectants and Disinfection Byproducts Sampling Information**

Guidance on monitoring for the Disinfectants and Disinfection Byproducts rule and how to identify sampling locations and use of the Sample Monitoring Point Identifiers (SMPIDs) can be found in the "Ohio EPA Sample Monitoring Plan Template for Disinfectants and Disinfection Byproducts". An electronic version of the template is located at <http://www.epa.state.oh.us/ddagw/Documents/new-ddbp-smp3.PDF>. A copy of this document is also available from your local Ohio EPA District Office. Any questions concerning this schedule or the Disinfectants and Disinfection Byproducts Rule can be directed to Richard Ciotola of the Ohio EPA DDAGW Central Office at (614) 644-3387 or [richard.ciotola@epa.state.oh.us](mailto:richard.ciotola@epa.state.oh.us). Your district office representative is also available to provide assistance.

Multiple wells drawing water from a single aquifer may be considered one treatment plant for determining the number of TTHM and HAA5 samples required, with approval from Ohio EPA.

\* Total chlorine samples are collected in the distribution system at the same time and place as total coliforms are sampled.

\*\* One sample for Chlorite at each of the following locations: near the first customer, at a location representative of the average residence time, and at a location reflecting maximum residence time of the water in the distribution system.

**Asbestos Sampling Information**

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

## Lead and Copper Monitoring Schedule

Triennial		
Sampling Period		Report is due to your district office no later than
Start	End	
6/1/04	9/30/04	10/10/04

System size (number of people served)	Number of sites (reduced monitoring)
> 100,000	50
10,001 to 100,000	30
3,301 to 10,000	20
501 to 3,000	10
101 to 500	5
< 101	5

The dates and number of samples noted above supercede any previous schedule received from this agency. Copies of EPA Forms 5105, 5106, and 5107 are available on our web site at <http://www.epa.state.oh.us/ddagw/drinkforms.htm> or your district office to use for your next report. If your Lead and Copper monitoring does exceed an action level or if you have any other questions, please contact your district representative at Central District Office at (614) 728-3778

**2004 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

PWS NAME: St. Catherine's Care Center PWS PWS TYPE: Community Ground Water

PWS ID: 2400912 **Sample Monitoring Point: EP001**

STU NAME: Saint Catherine's Care Center STU ID: 2454046

Effective Date: 1/1/04

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact Central District Office at (614) 728-3778 to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule.

**Chemicals** **2004** **Date Samples Taken**

Chemicals	2004	Date Samples Taken
INORGANICS	Not Required	
NITRATE	1 Sample between Jan 1 and Jun 30	
NITRITE	1 Sample between Jan 1 and Jun 30	
BROMATE	Not Required	
CHLORINE DIOXIDE	Not Required	
CHLORITE	Not Required	
VOLATILE ORGANIC CHEMICALS (VOC's)	Not Required	
SYNTHETIC ORGANIC CHEMICALS (SOC's)	Not Required	
RADIOLOGICALS	Alpha, total Radium-228	Not Required

\* A paired sample set refers to one source water and one treated water sample. A source water alkalinity is also required at the same time the TOC sample is taken.

**2004 CHEMICAL MONITORING DISTRIBUTION SCHEDULE**  
PWS ID: 2400912 PWS Name: St. Catherine's Care Center PWS  
Community Ground Water POPULATION: 50  
Effective Date: 1/1/04

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district representative at Central District Office at (614) 728-3778 to review additional monitoring for total coliform, minimum requirements for chemical analysis for your monthly operating reports, and/or other monitoring requirements not included on this schedule.

Chemicals	2004	Date Samples Taken
-----------	------	--------------------

Total Chlorine	Sample in the distribution system *	
Haloacetic Acids (five) (HAA5)	1 Sample between Jul 1 and Sept 30	
Total Trihalomethanes (TTHM)	1 Sample between Jul 1 and Sept 30	
Asbestos	Not Required	
Chlorite	Not Required	

**Disinfectants and Disinfection Byproducts Sampling Information**

Guidance on monitoring for the Disinfectants and Disinfection Byproducts rule and how to identify sampling locations and use of the Sample Monitoring Point Identifiers (SMPIDs) can be found in the "Ohio EPA Sample Monitoring Plan Template for Disinfectants and Disinfection Byproducts". An electronic version of the template is located at <http://www.epa.state.oh.us/ddagw/Documents/new-ddbp-smp3.PDF>. A copy of this document is also available from your local Ohio EPA District Office. Any questions concerning this schedule or the Disinfectants and Disinfection Byproducts Rule can be directed to Richard Ciotola of the Ohio EPA DDAGW Central Office at (614) 644-3387 or [richard.ciotola@epa.state.oh.us](mailto:richard.ciotola@epa.state.oh.us). Your district office representative is also available to provide assistance.

Multiple wells drawing water from a single aquifer may be considered one treatment plant for determining the number of TTHM and HAA5 samples required, with approval from Ohio EPA.

\* Total chlorine samples are collected in the distribution system at the same time and place as total coliforms are sampled.

\*\* One sample for Chlorite at each of the following locations: near the first customer, at a location representative of the average residence time, and at a location reflecting maximum residence time of the water in the distribution system.

**Asbestos Sampling Information**

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

## Lead and Copper Monitoring Schedule

Annual		
Sampling Period		Report is due to your district office no later than
Start	End	
6/1/04	9/30/04	10/10/04

System size (number of people served)	Number of sites (reduced monitoring)
> 100,000	50
10,001 to 100,000	30
3,301 to 10,000	20
501 to 3,000	10
101 to 500	5
< 101	5

The dates and number of samples noted above supercede any previous schedule received from this agency. Copies of EPA Forms 5105, 5106, and 5107 are available on our web site at <http://www.epa.state.oh.us/ddagw/drinkforms.htm> or your district office to use for your next report. If your Lead and Copper monitoring does exceed an action level or if you have any other questions, please contact your district representative at Central District Office at (614) 728-3778

---

---

**2004 CHEMICAL MONITORING SCHEDULE**

Walnut Lake Campground

PWS ID: 2435612 **Sample Monitoring Point: EP001**

STU NAME: Walnut Lake Campground STU ID: 2454064

Transient Noncommunity Ground Water

Effective Date: 1/1/04

---

---

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact Central District Office at (614) 728-3778 to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule.

**Chemicals**

**2004**

NITRATE	1 Sample between Jan 1 and Jun 30 Date Sample Taken: _____
NITRITE	Not Required

**NOTE: Check with your district office regarding your coliform monitoring requirements.**

**2004 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

PWS NAME: Washington Court House PWS PWS TYPE: Community Surface Water

PWS ID: 2400714 **Sample Monitoring Point: EP001**

STU NAME: Washington Court House PWS STU ID: 2454045

Effective Date: 1/1/04

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact Central District Office at (614) 728-3778 to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule.

Chemicals	2004	Date Samples Taken
INORGANICS	Antimony, total Arsenic, total Barium, total Beryllium, total Cadmium, total Chromium, total Cyanide, total Fluoride, total Mercury, total Nickel, total Selenium, total Thallium, total	1 Sample between Jan 1 and Jun 30
NITRATE		1 Sample Monthly
NITRITE		1 Sample between Jan 1 and Jun 30
ORGANIC CARBON		1 Paired Sample Set Monthly*
BROMATE		Not Required
CHLORINE DIOXIDE		Not Required
CHLORITE		Not Required
VOLATILE ORGANIC CHEMICALS (VOC's)		1 Sample between Jan 1 and Jun 30
SYNTHETIC ORGANIC CHEMICALS (SOC's)	Alachlor Atrazine Simazine	1 Sample between May 1 and Jul 31
	2,4-Dichlorophenoxyacetic acid Benzo(a)pyrene Carbofuran Di(2-ethylhexyl)adipate Di(2-ethylhexyl)phthalate Diquat Endothall Glyphosate Lindane Methoxychlor Oxamyl Pentachlorophenol Picloram Polychlorinated biphenyls	1 Sample between May 1 and Jul 31
RADIOLOGICALS	Alpha, total Radium-228	Not Required

\* A paired sample set refers to one source water and one treated water sample. A source water alkalinity is also required at the same time the TOC sample is taken.

**2004 CHEMICAL MONITORING DISTRIBUTION SCHEDULE**  
PWS ID: 2400714 PWS Name: Washington Court House PWS  
Community Surface Water POPULATION: 13980  
Effective Date: 1/1/04

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district representative at Central District Office at (614) 728-3778 to review additional monitoring for total coliform, minimum requirements for chemical analysis for your monthly operating reports, and/or other monitoring requirements not included on this schedule.

Chemicals	2004	Date Samples Taken
-----------	------	--------------------

Total Chlorine	Sample in the distribution system *	
Haloacetic Acids (five) (HAA5)	1 Sample each quarter (Jan-Mar, Apr-Jun, Jul-Sep, Oct-Dec)	
Total Trihalomethanes (TTHM)	1 Sample each quarter (Jan-Mar, Apr-Jun, Jul-Sep, Oct-Dec)	
Asbestos	Not Required	
Chlorite	Not Required	

**Disinfectants and Disinfection Byproducts Sampling Information**

Guidance on monitoring for the Disinfectants and Disinfection Byproducts rule and how to identify sampling locations and use of the Sample Monitoring Point Identifiers (SMPIDs) can be found in the "Ohio EPA Sample Monitoring Plan Template for Disinfectants and Disinfection Byproducts". An electronic version of the template is located at <http://www.epa.state.oh.us/ddagw/Documents/new-ddbp-smp3.PDF>. A copy of this document is also available from your local Ohio EPA District Office. Any questions concerning this schedule or the Disinfectants and Disinfection Byproducts Rule can be directed to Richard Ciotola of the Ohio EPA DDAGW Central Office at (614) 644-3387 or [richard.ciotola@epa.state.oh.us](mailto:richard.ciotola@epa.state.oh.us). Your district office representative is also available to provide assistance.

Multiple wells drawing water from a single aquifer may be considered one treatment plant for determining the number of TTHM and HAA5 samples required, with approval from Ohio EPA.

\* Total chlorine samples are collected in the distribution system at the same time and place as total coliforms are sampled.

\*\* One sample for Chlorite at each of the following locations: near the first customer, at a location representative of the average residence time, and at a location reflecting maximum residence time of the water in the distribution system.

**Asbestos Sampling Information**

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

## Lead and Copper Monitoring Schedule

Triennial		
Sampling Period		Report is due to your district office no later than
Start	End	
6/1/04	9/30/04	10/10/04

System size (number of people served)	Number of sites (reduced monitoring)
> 100,000	50
10,001 to 100,000	30
3,301 to 10,000	20
501 to 3,000	10
101 to 500	5
< 101	5

The dates and number of samples noted above supercede any previous schedule received from this agency. Copies of EPA Forms 5105, 5106, and 5107 are available on our web site at <http://www.epa.state.oh.us/ddagw/drinkforms.htm> or your district office to use for your next report. If your Lead and Copper monitoring does exceed an action level or if you have any other questions, please contact your district representative at Central District Office at (614) 728-3778

**2004 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

PWS NAME: Wayne Elementary School PWS TYPE: Nontransient Noncommunity Ground Water

PWS ID: 2435812 **Sample Monitoring Point: EP001**

STU NAME: Wayne Elementary School STU ID: 2454065

Effective Date: 1/1/04

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact Central District Office at (614) 728-3778 to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule.

**Chemicals** **2004** **Date Samples Taken**

Chemicals	2004	Date Samples Taken
INORGANICS	Not Required	
NITRATE	1 Sample between Jan 1 and Jun 30	
NITRITE	1 Sample between Jan 1 and Jun 30	
BROMATE	Not Required	
CHLORINE DIOXIDE	Not Required	
CHLORITE	Not Required	
VOLATILE ORGANIC CHEMICALS (VOC's)	Not Required	
SYNTHETIC ORGANIC CHEMICALS (SOC's)	Not Required	

\* A paired sample set refers to one source water and one treated water sample. A source water alkalinity is also required at the same time the TOC sample is taken.

**2004 CHEMICAL MONITORING DISTRIBUTION SCHEDULE**  
PWS ID: 2435812 PWS Name: Wayne Elementary School  
Nontransient Noncommunity Ground Water POPULATION: 284  
Effective Date: 1/1/04

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district representative at Central District Office at (614) 728-3778 to review additional monitoring for total coliform, minimum requirements for chemical analysis for your monthly operating reports, and/or other monitoring requirements not included on this schedule.

Chemicals	2004	Date Samples Taken
-----------	------	--------------------

Asbestos	Not Required	
Chlorite	Not Required	
Haloacetic Acids (five) (HAA5)	Not Required	
Total Trihalomethanes (TTHM)	Not Required	

**Disinfectants and Disinfection Byproducts Sampling Information**

Guidance on monitoring for the Disinfectants and Disinfection Byproducts rule and how to identify sampling locations and use of the Sample Monitoring Point Identifiers (SMPIDs) can be found in the "Ohio EPA Sample Monitoring Plan Template for Disinfectants and Disinfection Byproducts". An electronic version of the template is located at <http://www.epa.state.oh.us/ddagw/Documents/new-ddbp-smp3.PDF>. A copy of this document is also available from your local Ohio EPA District Office. Any questions concerning this schedule or the Disinfectants and Disinfection Byproducts Rule can be directed to Richard Ciotola of the Ohio EPA DDAGW Central Office at (614) 644-3387 or [richard.ciotola@epa.state.oh.us](mailto:richard.ciotola@epa.state.oh.us). Your district office representative is also available to provide assistance.

Multiple wells drawing water from a single aquifer may be considered one treatment plant for determining the number of TTHM and HAA5 samples required, with approval from Ohio EPA.

\* Total chlorine samples are collected in the distribution system at the same time and place as total coliforms are sampled.

\*\* One sample for Chlorite at each of the following locations: near the first customer, at a location representative of the average residence time, and at a location reflecting maximum residence time of the water in the distribution system.

**Asbestos Sampling Information**

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

---

---

**2004 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

PWS NAME: Wilson Elementary School PWS TYPE: Nontransient Noncommunity Ground Water

PWS ID: 2436112 **Sample Monitoring Point: EP001**

STU NAME: Wilson Elementary School STU ID: 2454066

Effective Date: 1/1/04

---

---

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact Central District Office at (614) 728-3778 to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule.

**Chemicals** **2004** **Date Samples Taken**

Chemicals	2004	Date Samples Taken
INORGANICS	Not Required	
NITRATE	1 Sample between Jan 1 and Jun 30	
NITRITE	1 Sample between Jan 1 and Jun 30	
BROMATE	Not Required	
CHLORINE DIOXIDE	Not Required	
CHLORITE	Not Required	
VOLATILE ORGANIC CHEMICALS (VOC's)	Not Required	
SYNTHETIC ORGANIC CHEMICALS (SOC's)	Not Required	

\* A paired sample set refers to one source water and one treated water sample. A source water alkalinity is also required at the same time the TOC sample is taken.

---

---

**2004 CHEMICAL MONITORING DISTRIBUTION SCHEDULE**

PWS ID: 2436112 PWS Name: Wilson Elementary School

Nontransient Noncommunity Ground Water POPULATION: 178

Effective Date: 1/1/04

---

---

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district representative at Central District Office at (614) 728-3778 to review additional monitoring for total coliform, minimum requirements for chemical analysis for your monthly operating reports, and/or other monitoring requirements not included on this schedule.

**Chemicals**

**2004**

**Date Samples Taken**

Chemicals	2004	Date Samples Taken
Asbestos	Not Required	
Chlorite	Not Required	
Haloacetic Acids (five) (HAA5)	Not Required	
Total Trihalomethanes (TTHM)	Not Required	

**Disinfectants and Disinfection Byproducts Sampling Information**

Guidance on monitoring for the Disinfectants and Disinfection Byproducts rule and how to identify sampling locations and use of the Sample Monitoring Point Identifiers (SMPIDs) can be found in the "Ohio EPA Sample Monitoring Plan Template for Disinfectants and Disinfection Byproducts". An electronic version of the template is located at <http://www.epa.state.oh.us/ddagw/Documents/new-ddbp-smp3.PDF>. A copy of this document is also available from your local Ohio EPA District Office. Any questions concerning this schedule or the Disinfectants and Disinfection Byproducts Rule can be directed to Richard Ciotola of the Ohio EPA DDAGW Central Office at (614) 644-3387 or [richard.ciotola@epa.state.oh.us](mailto:richard.ciotola@epa.state.oh.us). Your district office representative is also available to provide assistance.

Multiple wells drawing water from a single aquifer may be considered one treatment plant for determining the number of TTHM and HAA5 samples required, with approval from Ohio EPA.

\* Total chlorine samples are collected in the distribution system at the same time and place as total coliforms are sampled.

\*\* One sample for Chlorite at each of the following locations: near the first customer, at a location representative of the average residence time, and at a location reflecting maximum residence time of the water in the distribution system.

**Asbestos Sampling Information**

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.