

---

---

**2004 CHEMICAL MONITORING SCHEDULE**

Bible Baptist Church Greenfield

PWS ID: 3631312 **Sample Monitoring Point: EP001**

STU NAME: Greenfield Bible Baptist STU ID: 3655032

Transient Noncommunity Ground Water

Effective Date: 1/1/04

---

---

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact Southwest District Office at (937) 285-6357 to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule.

**Chemicals**

**2004**

NITRATE	1 Sample between Jan 1 and Jun 30 Date Sample Taken: _____
NITRITE	Not Required

**NOTE: Check with your district office regarding your coliform monitoring requirements.**

---

---

**2004 CHEMICAL MONITORING SCHEDULE**

Cedar Hill Campground

PWS ID: 3637012 **Sample Monitoring Point: EP001**

STU NAME: Cedar Hill Campground STU ID: 3655044

Transient Noncommunity Ground Water

Effective Date: 1/1/04

---

---

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact Southwest District Office at (937) 285-6357 to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule.

**Chemicals**

**2004**

NITRATE	1 Sample between Jan 1 and Jun 30 Date Sample Taken: _____
NITRITE	Not Required

**NOTE: Check with your district office regarding your coliform monitoring requirements.**

---

---

**2004 CHEMICAL MONITORING SCHEDULE**

Country Corner Market PWS

PWS ID: 3634412 **Sample Monitoring Point: EP001**

STU NAME: Country Corner Market STU ID: 3660933

Transient Noncommunity Ground Water

Effective Date: 1/1/04

---

---

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact Southwest District Office at (937) 285-6357 to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule.

**Chemicals**

**2004**

NITRATE	1 Sample between Jan 1 and Jun 30 Date Sample Taken: _____
NITRITE	Not Required

**NOTE: Check with your district office regarding your coliform monitoring requirements.**

---

---

**2004 CHEMICAL MONITORING SCHEDULE**

Good Shepherd U B Church

PWS ID: 3636812 **Sample Monitoring Point: EP001**

STU NAME: United Brethren Church STU ID: 3655042

Transient Noncommunity Ground Water

Effective Date: 1/1/04

---

---

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact Southwest District Office at (937) 285-6357 to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule.

**Chemicals**

**2004**

NITRATE	1 Sample between Jan 1 and Jun 30 Date Sample Taken: _____
NITRITE	Not Required

**NOTE: Check with your district office regarding your coliform monitoring requirements.**

**2004 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

PWS NAME: Greenfield, City Of PWS TYPE: Community Ground Water

PWS ID: 3600312 **Sample Monitoring Point: EP001**

STU NAME: Greenfield Water Department STU ID: 3655021

Effective Date: 1/1/04

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact Southwest District Office at (937) 285-6357 to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule.

Chemicals	2004	Date Samples Taken
-----------	------	--------------------

INORGANICS	Not Required	
NITRATE	1 Sample between Jul 1 and Sep 30	
NITRITE	1 Sample between Jan 1 and Jun 30	
BROMATE	Not Required	
CHLORINE DIOXIDE	Not Required	
CHLORITE	Not Required	
VOLATILE ORGANIC CHEMICALS (VOC's)	Not Required	
SYNTHETIC ORGANIC CHEMICALS (SOC's)		
	2,4-Dichlorophenoxyacetic acid 1 Sample between Apr 1 and Jun 30 Benzo(a)pyrene Carbofuran Di(2-ethylhexyl)adipate Di(2-ethylhexyl)phthalate Diquat Endothall Glyphosate Lindane Methoxychlor Oxamyl Pentachlorophenol Picloram Polychlorinated biphenyls	
RADIOLOGICALS	Alpha, total Radium-228	Not Required

\* A paired sample set refers to one source water and one treated water sample. A source water alkalinity is also required at the same time the TOC sample is taken.

**2004 CHEMICAL MONITORING DISTRIBUTION SCHEDULE**

PWS ID: 3600312 PWS Name: Greenfield, City Of  
Community Ground Water POPULATION: 5172  
Effective Date: 1/1/04

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district representative at Southwest District Office at (937) 285-6357 to review additional monitoring for total coliform, minimum requirements for chemical analysis for your monthly operating reports, and/or other monitoring requirements not included on this schedule.

<b>Chemicals</b>	<b>2004</b>	<b>Date Samples Taken</b>
------------------	-------------	---------------------------

Asbestos	1 sample between Apr 1 and Jun 30	
Total Chlorine	Sample in the distribution system *	
Haloacetic Acids (five) (HAA5)	1 Sample between Jul 1 and Sept 30	
Total Trihalomethanes (TTHM)	1 Sample between Jul 1 and Sept 30	
Chlorite	Not Required	

**Disinfectants and Disinfection Byproducts Sampling Information**

Guidance on monitoring for the Disinfectants and Disinfection Byproducts rule and how to identify sampling locations and use of the Sample Monitoring Point Identifiers (SMPIDs) can be found in the "Ohio EPA Sample Monitoring Plan Template for Disinfectants and Disinfection Byproducts". An electronic version of the template is located at <http://www.epa.state.oh.us/ddagw/Documents/new-ddbp-smp3.PDF>. A copy of this document is also available from your local Ohio EPA District Office. Any questions concerning this schedule or the Disinfectants and Disinfection Byproducts Rule can be directed to Richard Ciotola of the Ohio EPA DDAGW Central Office at (614) 644-3387 or [richard.ciotola@epa.state.oh.us](mailto:richard.ciotola@epa.state.oh.us). Your district office representative is also available to provide assistance.

Multiple wells drawing water from a single aquifer may be considered one treatment plant for determining the number of TTHM and HAA5 samples required, with approval from Ohio EPA.

\* Total chlorine samples are collected in the distribution system at the same time and place as total coliforms are sampled.

\*\* One sample for Chlorite at each of the following locations: near the first customer, at a location representative of the average residence time, and at a location reflecting maximum residence time of the water in the distribution system.

**Asbestos Sampling Information**

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

**2004 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

PWS NAME: Highland County Water Company, Inc. PWS TYPE: Community Ground Water

PWS ID: 3600514 **Sample Monitoring Point: EP001**

STU NAME: Highland County Water Co Inc STU ID: 3655022

Effective Date: 1/1/04

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact Southwest District Office at (937) 285-6357 to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule.

<b>Chemicals</b>	<b>2004</b>	<b>Date Samples Taken</b>
INORGANICS	Not Required	
NITRATE	1 Sample between Jan 1 and Jun 30	
NITRITE	1 Sample between Jan 1 and Jun 30	
BROMATE	Not Required	
CHLORINE DIOXIDE	Not Required	
CHLORITE	Not Required	
VOLATILE ORGANIC CHEMICALS (VOC's)	Not Required	
SYNTHETIC ORGANIC CHEMICALS (SOC's)	Not Required	
RADIOLOGICALS	Alpha, total Radium-228 Not Required	

\* A paired sample set refers to one source water and one treated water sample. A source water alkalinity is also required at the same time the TOC sample is taken.

**2004 CHEMICAL MONITORING DISTRIBUTION SCHEDULE**  
PWS ID: 3600514 PWS Name: Highland County Water Company, Inc.  
Community Ground Water POPULATION: 30450  
Effective Date: 1/1/04

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district representative at Southwest District Office at (937) 285-6357 to review additional monitoring for total coliform, minimum requirements for chemical analysis for your monthly operating reports, and/or other monitoring requirements not included on this schedule.

<b>Chemicals</b>	<b>2004</b>	<b>Date Samples Taken</b>
Asbestos	1 sample between Apr 1 and Jun 30	
Total Chlorine	Sample in the distribution system *	
Haloacetic Acids (five) (HAA5)	1 Sample each quarter (Jan-Mar, Apr-Jun, Jul-Sep, Oct-Dec)	
Total Trihalomethanes (TTHM)	1 Sample each quarter (Jan-Mar, Apr-Jun, Jul-Sep, Oct-Dec)	
Chlorite	Not Required	

**Disinfectants and Disinfection Byproducts Sampling Information**

Guidance on monitoring for the Disinfectants and Disinfection Byproducts rule and how to identify sampling locations and use of the Sample Monitoring Point Identifiers (SMPIDs) can be found in the "Ohio EPA Sample Monitoring Plan Template for Disinfectants and Disinfection Byproducts". An electronic version of the template is located at <http://www.epa.state.oh.us/ddagw/Documents/new-ddbp-smp3.PDF>. A copy of this document is also available from your local Ohio EPA District Office. Any questions concerning this schedule or the Disinfectants and Disinfection Byproducts Rule can be directed to Richard Ciotola of the Ohio EPA DDAGW Central Office at (614) 644-3387 or [richard.ciotola@epa.state.oh.us](mailto:richard.ciotola@epa.state.oh.us). Your district office representative is also available to provide assistance.

Multiple wells drawing water from a single aquifer may be considered one treatment plant for determining the number of TTHM and HAA5 samples required, with approval from Ohio EPA.

\* Total chlorine samples are collected in the distribution system at the same time and place as total coliforms are sampled.

\*\* One sample for Chlorite at each of the following locations: near the first customer, at a location representative of the average residence time, and at a location reflecting maximum residence time of the water in the distribution system.

**Asbestos Sampling Information**

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

**2004 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

PWS NAME: Hillsboro, City Of PWS TYPE: Community Surface Water

PWS ID: 3600614 **Sample Monitoring Point: EP001**

STU NAME: Hillsboro WTP STU ID: 3655023

Effective Date: 1/1/04

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact Southwest District Office at (937) 285-6357 to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule.

Chemicals	2004	Date Samples Taken
INORGANICS	Antimony, total Arsenic, total Barium, total Beryllium, total Cadmium, total Chromium, total Cyanide, total Fluoride, total Mercury, total Nickel, total Selenium, total Thallium, total	1 Sample between Jan 1 and Jun 30
NITRATE		1 Sample Monthly
NITRITE		1 Sample between Jan 1 and Jun 30
ORGANIC CARBON		1 Paired Sample Set Monthly*
BROMATE		Not Required
CHLORINE DIOXIDE		Not Required
CHLORITE		Not Required
VOLATILE ORGANIC CHEMICALS (VOC's)		1 Sample between Jan 1 and Jun 30
SYNTHETIC ORGANIC CHEMICALS (SOC's)	Alachlor Atrazine Simazine	1 Sample between Feb 1 and Apr 30 1 Sample in May 1 Sample in June 1 Sample in July 1 Sample between Aug 1 and Oct 31 1 Sample between Nov 1 and Jan 31 (2004)
RADIOLOGICALS	Alpha, total Radium-228	Not Required

\* A paired sample set refers to one source water and one treated water sample. A source water alkalinity is also required at the same time the TOC sample is taken.

## 2004 CHEMICAL MONITORING DISTRIBUTION SCHEDULE

PWS ID: 3600614 PWS Name: Hillsboro, City Of  
Community Surface Water POPULATION: 6368  
Effective Date: 1/1/04

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district representative at Southwest District Office at (937) 285-6357 to review additional monitoring for total coliform, minimum requirements for chemical analysis for your monthly operating reports, and/or other monitoring requirements not included on this schedule.

Chemicals	2004	Date Samples Taken
-----------	------	--------------------

Total Chlorine	Sample in the distribution system *	
Haloacetic Acids (five) (HAA5)	1 Sample each quarter (Jan-Mar, Apr-Jun, Jul-Sep, Oct-Dec)	
Total Trihalomethanes (TTHM)	1 Sample each quarter (Jan-Mar, Apr-Jun, Jul-Sep, Oct-Dec)	
Asbestos	Not Required	
Chlorite	Not Required	

**Disinfectants and Disinfection Byproducts Sampling Information**

Guidance on monitoring for the Disinfectants and Disinfection Byproducts rule and how to identify sampling locations and use of the Sample Monitoring Point Identifiers (SMPIDs) can be found in the "Ohio EPA Sample Monitoring Plan Template for Disinfectants and Disinfection Byproducts". An electronic version of the template is located at <http://www.epa.state.oh.us/ddagw/Documents/new-ddbp-smp3.PDF>. A copy of this document is also available from your local Ohio EPA District Office. Any questions concerning this schedule or the Disinfectants and Disinfection Byproducts Rule can be directed to Richard Ciotola of the Ohio EPA DDAGW Central Office at (614) 644-3387 or [richard.ciotola@epa.state.oh.us](mailto:richard.ciotola@epa.state.oh.us). Your district office representative is also available to provide assistance.

Multiple wells drawing water from a single aquifer may be considered one treatment plant for determining the number of TTHM and HAA5 samples required, with approval from Ohio EPA.

\* Total chlorine samples are collected in the distribution system at the same time and place as total coliforms are sampled.

\*\* One sample for Chlorite at each of the following locations: near the first customer, at a location representative of the average residence time, and at a location reflecting maximum residence time of the water in the distribution system.

**Asbestos Sampling Information**

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

## Lead and Copper Monitoring Schedule

Triennial		
Sampling Period		Report is due to your district office no later than
Start	End	
6/1/04	9/30/04	10/10/04

System size (number of people served)	Number of sites (reduced monitoring)
> 100,000	50
10,001 to 100,000	30
3,301 to 10,000	20
501 to 3,000	10
101 to 500	5
< 101	5

The dates and number of samples noted above supercede any previous schedule received from this agency. Copies of EPA Forms 5105, 5106, and 5107 are available on our web site at <http://www.epa.state.oh.us/ddagw/drinkforms.htm> or your district office to use for your next report. If your Lead and Copper monitoring does exceed an action level or if you have any other questions, please contact your district representative at Southwest District Office at (937) 285-6357

**2004 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

PWS NAME: Leesburg Amish School    PWS TYPE: Nontransient Noncommunity Ground Water

PWS ID: 3636912    **Sample Monitoring Point: EP001**

STU NAME: Leesburg Amish School    STU ID: 3655043

Effective Date: 1/1/04

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact Southwest District Office at (937) 285-6357 to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule.

Chemicals	2004	Date Samples Taken
-----------	------	--------------------

INORGANICS	Not Required	
NITRATE	1 Sample between Jan 1 and Jun 30	
NITRITE	1 Sample between Jan 1 and Jun 30	
BROMATE	Not Required	
CHLORINE DIOXIDE	Not Required	
CHLORITE	Not Required	
VOLATILE ORGANIC CHEMICALS (VOC's)	Not Required	
SYNTHETIC ORGANIC CHEMICALS (SOC's)	Not Required	

\* A paired sample set refers to one source water and one treated water sample. A source water alkalinity is also required at the same time the TOC sample is taken.

**REVISED 2004 CHEMICAL MONITORING DISTRIBUTION SCHEDULE**

PWS ID: 3636912 PWS Name: Leesburg Amish School

Nontransient Noncommunity Ground Water POPULATION: 25

Effective Date 6/1/04

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district representative at Southwest District Office at (937) 285-6357 to review additional monitoring for total coliform, minimum requirements for chemical analysis for your monthly operating reports, and/or other monitoring requirements not included on this schedule.

<b>Chemicals</b>	<b>2004</b>	<b>Date Samples Taken</b>
------------------	-------------	---------------------------

Asbestos	Not Required	
Chlorite	Not Required	
Haloacetic Acids (five) (HAA5)	Not Required	
Total Trihalomethanes (TTHM)	Not Required	

**Disinfectants and Disinfection Byproducts Sampling Information**

Guidance on monitoring for the Disinfectants and Disinfection Byproducts rule and how to identify sampling locations and use of the Sample Monitoring Point Identifiers (SMPIDs) can be found in the "Ohio EPA Sample Monitoring Plan Template for Disinfectants and Disinfection Byproducts". An electronic version of the template is located at <http://www.epa.state.oh.us/ddagw/Documents/new-ddbp-smp3.PDF>. A copy of this document is also available from your local Ohio EPA District Office. Any questions concerning this schedule or the Disinfectants and Disinfection Byproducts Rule can be directed to Richard Ciotola of the Ohio EPA DDAGW Central Office at (614) 644-3387 or [richard.ciotola@epa.state.oh.us](mailto:richard.ciotola@epa.state.oh.us). Your district office representative is also available to provide assistance.

Multiple wells drawing water from a single aquifer may be considered one treatment plant for determining the number of TTHM and HAA5 samples required, with approval from Ohio EPA.

\* Total chlorine samples are collected in the distribution system at the same time and place as total coliforms are sampled.

\*\* One sample for Chlorite at each of the following locations: near the first customer, at a location representative of the average residence time, and at a location reflecting maximum residence time of the water in the distribution system.

**Asbestos Sampling Information**

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

**2004 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

PWS NAME: Leesburg, Village Of PWS TYPE: Community Ground Water

PWS ID: 3600712 **Sample Monitoring Point: EP001**

STU NAME: Leesburg WTP STU ID: 3655024

Effective Date: 1/1/04

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact Southwest District Office at (937) 285-6357 to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule.

<b>Chemicals</b>	<b>2004</b>	<b>Date Samples Taken</b>
INORGANICS	Not Required	
NITRATE	1 Sample between Jan 1 and Jun 30	
NITRITE	1 Sample between Jan 1 and Jun 30	
BROMATE	Not Required	
CHLORINE DIOXIDE	Not Required	
CHLORITE	Not Required	
VOLATILE ORGANIC CHEMICALS (VOC's)	Not Required	
SYNTHETIC ORGANIC CHEMICALS (SOC's)	Not Required	
RADIOLOGICALS	Alpha, total Radium-228	Not Required

\* A paired sample set refers to one source water and one treated water sample. A source water alkalinity is also required at the same time the TOC sample is taken.

## 2004 CHEMICAL MONITORING DISTRIBUTION SCHEDULE

PWS ID: 3600712 PWS Name: Leesburg,Village Of

Community Ground Water POPULATION: 1200

Effective Date: 1/1/04

### THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district representative at Southwest District Office at (937) 285-6357 to review additional monitoring for total coliform, minimum requirements for chemical analysis for your monthly operating reports, and/or other monitoring requirements not included on this schedule.

Chemicals	2004	Date Samples Taken
-----------	------	--------------------

Asbestos	1 sample between Apr 1 and Jun 30	
Total Chlorine	Sample in the distribution system *	
Haloacetic Acids (five) (HAA5)	1 Sample between Jul 1 and Sept 30	
Total Trihalomethanes (TTHM)	1 Sample between Jul 1 and Sept 30	
Chlorite	Not Required	

#### Disinfectants and Disinfection Byproducts Sampling Information

Guidance on monitoring for the Disinfectants and Disinfection Byproducts rule and how to identify sampling locations and use of the Sample Monitoring Point Identifiers (SMPIDs) can be found in the "Ohio EPA Sample Monitoring Plan Template for Disinfectants and Disinfection Byproducts". An electronic version of the template is located at <http://www.epa.state.oh.us/ddagw/Documents/new-ddbp-smp3.PDF>. A copy of this document is also available from your local Ohio EPA District Office. Any questions concerning this schedule or the Disinfectants and Disinfection Byproducts Rule can be directed to Richard Ciotola of the Ohio EPA DDAGW Central Office at (614) 644-3387 or [richard.ciotola@epa.state.oh.us](mailto:richard.ciotola@epa.state.oh.us). Your district office representative is also available to provide assistance.

Multiple wells drawing water from a single aquifer may be considered one treatment plant for determining the number of TTHM and HAA5 samples required, with approval from Ohio EPA.

\* Total chlorine samples are collected in the distribution system at the same time and place as total coliforms are sampled.

\*\* One sample for Chlorite at each of the following locations: near the first customer, at a location representative of the average residence time, and at a location reflecting maximum residence time of the water in the distribution system.

#### Asbestos Sampling Information

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

**2004 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

PWS NAME: Lynchburg, Village Of PWS TYPE: Community Ground Water

PWS ID: 3600915 **Sample Monitoring Point: EP001**

STU NAME: Lynchburg Water Department STU ID: 3655025

Effective Date: 1/1/04

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact Southwest District Office at (937) 285-6357 to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule.

<b>Chemicals</b>	<b>2004</b>	<b>Date Samples Taken</b>
INORGANICS	Not Required	
NITRATE	1 Sample between Jan 1 and Jun 30	
NITRITE	1 Sample between Jan 1 and Jun 30	
BROMATE	Not Required	
CHLORINE DIOXIDE	Not Required	
CHLORITE	Not Required	
VOLATILE ORGANIC CHEMICALS (VOC's)	Not Required	
SYNTHETIC ORGANIC CHEMICALS (SOC's)	Not Required	
RADIOLOGICALS	Alpha, total Radium-228	Not Required

\* A paired sample set refers to one source water and one treated water sample. A source water alkalinity is also required at the same time the TOC sample is taken.

**REVISED 2004 CHEMICAL MONITORING DISTRIBUTION SCHEDULE**

PWS ID: 3600915 PWS Name: Lynchburg, Village Of  
Community Ground Water POPULATION: 1350  
Effective Date: 3/1/04

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district representative at Southwest District Office at (937) 285-6357 to review additional monitoring for total coliform, minimum requirements for chemical analysis for your monthly operating reports, and/or other monitoring requirements not included on this schedule.

<b>Chemicals</b>	<b>2004</b>	<b>Date Samples Taken</b>
Asbestos	1 sample between Jul 1 and Sept 30	
Total Chlorine	Sample in the distribution system *	
Haloacetic Acids (five) (HAA5)	1 Sample between Jul 1 and Sept 30	
Total Trihalomethanes (TTHM)	1 Sample between Jul 1 and Sept 30	
Chlorite	Not Required	

**Disinfectants and Disinfection Byproducts Sampling Information**

Guidance on monitoring for the Disinfectants and Disinfection Byproducts rule and how to identify sampling locations and use of the Sample Monitoring Point Identifiers (SMPIDs) can be found in the "Ohio EPA Sample Monitoring Plan Template for Disinfectants and Disinfection Byproducts". An electronic version of the template is located at <http://www.epa.state.oh.us/ddagw/Documents/new-ddbp-smp3.PDF>. A copy of this document is also available from your local Ohio EPA District Office. Any questions concerning this schedule or the Disinfectants and Disinfection Byproducts Rule can be directed to Richard Ciotola of the Ohio EPA DDAGW Central Office at (614) 644-3387 or [richard.ciotola@epa.state.oh.us](mailto:richard.ciotola@epa.state.oh.us). Your district office representative is also available to provide assistance.

Multiple wells drawing water from a single aquifer may be considered one treatment plant for determining the number of TTHM and HAA5 samples required, with approval from Ohio EPA.

\* Total chlorine samples are collected in the distribution system at the same time and place as total coliforms are sampled.

\*\* One sample for Chlorite at each of the following locations: near the first customer, at a location representative of the average residence time, and at a location reflecting maximum residence time of the water in the distribution system.

**Asbestos Sampling Information**

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

---

---

**2004 CHEMICAL MONITORING SCHEDULE**

North Bay Cottages & Bai

PWS ID: 3632312 **Sample Monitoring Point: EP001**

STU NAME: North Bay Cottages & Bait Shop STU ID: 3655034

Transient Noncommunity Ground Water

Effective Date: 1/1/04

---

---

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact Southwest District Office at (937) 285-6357 to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule.

**Chemicals**

**2004**

NITRATE	1 Sample between Jan 1 and Jun 30 Date Sample Taken: _____
NITRITE	Not Required

**NOTE: Check with your district office regarding your coliform monitoring requirements.**

---

---

**2004 CHEMICAL MONITORING SCHEDULE**

Shady Trails Campground

PWS ID: 3632512 **Sample Monitoring Point: EP001**  
STU NAME: Shady Trails Campground STU ID: 3655035  
Transient Noncommunity Ground Water  
Effective Date: 1/1/04

---

---

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact Southwest District Office at (937) 285-6357 to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule.

**Chemicals**

**2004**

NITRATE	1 Sample between Jan 1 and Jun 30 Date Sample Taken: _____
NITRITE	Not Required

**NOTE: Check with your district office regarding your coliform monitoring requirements.**