

**2006 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

PWS NAME: Caldwell Village PWS    PWS TYPE: Community Surface Water

PWS ID: 6100011    **Sample Monitoring Point: EP001**

STU NAME: Caldwell WTP    STU ID: 6156878

Effective Date: 1/1/06

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact Southeast District Office at (740) 385-8501 to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals/Reports	Chemical Name (Code)	Monitoring Requirements	Sample Date
CONSUMER CONFIDENCE REPORT (CCR)		CCR due by July 1, 2006	
INORGANICS	Antimony, total (1074) Barium, total (1010) Beryllium, total (1075) Cadmium, total (1015) Chromium, total (1020) Cyanide, total (1024) Fluoride, total (1025) Mercury, total (1035) Nickel, total (1036) Selenium, total (1045) Thallium, total (1085)	1 Sample between Jun 1 and Oct 31	
ARSENIC	Arsenic, total (1005)	1 Sample between Jun 1 and Oct 31	
NITRATE	Nitrate (1040)	1 Sample Monthly	
NITRITE	Nitrite (1041)	Not Required	
RADIOLOGICALS	Alpha, total (4000) Radium-228 (4030)	Not Required	
BROMATE	Bromate (1011)	Not Required	
CHLORINE DIOXIDE	Chlorine dioxide (1008)	Not Required	
CHLORITE	Chlorite (1009)	Not Required	
TOTAL ORGANIC CARBON (TOC)	TOC (2920)	1 Paired Sample Set Monthly*	
VOLATILE ORGANIC CHEMICALS (VOCs)	VOCs	1 Sample between Apr 1 and Jun 30	
SYNTHETIC ORGANIC CHEMICALS (SOCs)	Alachlor (2051) Atrazine (2050) Simazine (2037)	1 Sample May 1 to Jul 31	
	<div style="border: 1px solid black; padding: 5px; background-color: #e0e0e0;"> <b>ATTENTION:</b>  <b>Some monitoring periods have been reduced from 6 months to 5 months. Please review the monitoring requirements carefully.</b> </div>		

\* A paired sample set refers to one source water and one treated water sample. A source water alkalinity is also required at the same time the TOC sample is taken.

**2006 CHEMICAL MONITORING DISTRIBUTION SCHEDULE**

PWS ID: 6100011 PWS Name: Caldwell Village PWS

Community Surface Water POPULATION: 7500

Effective Date: 1/1/06

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district representative at Southeast District Office at (740) 385-8501 to review additional monitoring for total coliform, minimum requirements for chemical analysis for your monthly operating reports, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals (Code)</b>	<b>Monitoring Requirements</b>	<b>Sample Date</b>
Total Chlorine (1000)	Sample in the distribution system *	
Haloacetic Acids, five (HAA5)	1 Sample each quarter (Jan-Mar, Apr-Jun, Jul-Sep, Oct-Dec)	
Total Trihalomethanes (TTHM)	1 Sample each quarter (Jan-Mar, Apr-Jun, Jul-Sep, Oct-Dec)	
Chlorite (1009)	Not Required	

**Disinfectants and Disinfection Byproducts Sampling Information**

TTHM and HAA5 sample(s) should be collected from point(s) in the distribution system where the water age is the oldest. Use the MR00# as the sample monitoring point. If your system is also required to collect TTHM and HAA5 samples from other locations in your distribution system, use the appropriate RD00# as the sample monitoring point. Any questions concerning this schedule or the Disinfectants and Disinfection Byproducts Rule can be directed to Todd Kelleher of the Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

Multiple wells drawing water from a single aquifer may be considered one treatment plant for determining the number of TTHM and HAA5 samples required, with approval from Ohio EPA.

\* Total chlorine samples are collected in the distribution system at the same time and place as total coliforms are sampled.

\*\* One sample for Chlorite at each of the following locations: near the first customer, at a location representative of the average residence time, and at a location reflecting maximum residence time of the water in the distribution system.

**Lead and Copper Tap Schedule**

**Routine Lead and Copper Tap Monitoring Not Required**

**If a lead or copper action level has been exceeded, additional sampling may be required.**

**2006 CHEMICAL MONITORING DISTRIBUTION SCHEDULE**

PWS ID: 6100103 PWS Name: Clear Water Corporation  
 Community Purchased Surface Water POPULATION: 2091  
 Effective Date: 1/1/06

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district representative at Southeast District Office at (740) 385-8501 to review additional monitoring for total coliform, minimum requirements for chemical analysis for your monthly operating reports, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals (Code)	Monitoring Requirements	Sample Date
Total Chlorine (1000)	Sample in the distribution system *	
Haloacetic Acids, five (HAA5)	1 Sample each quarter (Jan-Mar, Apr-Jun, Jul-Sep, Oct-Dec)	
Total Trihalomethanes (TTHM)	1 Sample each quarter (Jan-Mar, Apr-Jun, Jul-Sep, Oct-Dec)	
Chlorite (1009)	Not Required	

**Disinfectants and Disinfection Byproducts Sampling Information**

TTHM and HAA5 sample(s) should be collected from point(s) in the distribution system where the water age is the oldest. Use the MR00# as the sample monitoring point. If your system is also required to collect TTHM and HAA5 samples from other locations in your distribution system, use the appropriate RD00# as the sample monitoring point. Any questions concerning this schedule or the Disinfectants and Disinfection Byproducts Rule can be directed to Todd Kelleher of the Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

Multiple wells drawing water from a single aquifer may be considered one treatment plant for determining the number of TTHM and HAA5 samples required, with approval from Ohio EPA.

\* Total chlorine samples are collected in the distribution system at the same time and place as total coliforms are sampled.

\*\* One sample for Chlorite at each of the following locations: near the first customer, at a location representative of the average residence time, and at a location reflecting maximum residence time of the water in the distribution system.

**Lead and Copper Monitoring Schedule**

Triennial			System size (number of people served)	Number of sites (reduced monitoring)
Sampling Period		Report is due to your district office no later than		
Start	End			
06/01/2006	09/30/2006	10/10/06	2091	10

The dates and number of samples noted above supercede any previous schedule received from this agency. Copies of EPA Forms 5105, 5106, and 5107 are available on our web site at <http://www.epa.state.oh.us/ddagw/drinkforms.htm> or your district office to use for your next report. If your Lead and Copper monitoring does exceed an action level or if you have any other questions, please contact your district representative at Southeast District Office at (740) 385-8501

**2006 CHEMICAL MONITORING DISTRIBUTION SCHEDULE**  
PWS ID: 6100503 PWS Name: Noble County Water Authority PWS  
Community Purchased Surface Water POPULATION: 841  
Effective Date: 1/1/06

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district representative at Southeast District Office at (740) 385-8501 to review additional monitoring for total coliform, minimum requirements for chemical analysis for your monthly operating reports, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals (Code)	Monitoring Requirements	Sample Date
Total Chlorine (1000)	Sample in the distribution system *	
Haloacetic Acids, five (HAA5)	1 Sample each quarter (Jan-Mar, Apr-Jun, Jul-Sep, Oct-Dec)	
Total Trihalomethanes (TTHM)	1 Sample each quarter (Jan-Mar, Apr-Jun, Jul-Sep, Oct-Dec)	
Chlorite (1009)	Not Required	

**Disinfectants and Disinfection Byproducts Sampling Information**

TTHM and HAA5 sample(s) should be collected from point(s) in the distribution system where the water age is the oldest. Use the MR00# as the sample monitoring point. If your system is also required to collect TTHM and HAA5 samples from other locations in your distribution system, use the appropriate RD00# as the sample monitoring point. Any questions concerning this schedule or the Disinfectants and Disinfection Byproducts Rule can be directed to Todd Kelleher of the Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

Multiple wells drawing water from a single aquifer may be considered one treatment plant for determining the number of TTHM and HAA5 samples required, with approval from Ohio EPA.

\* Total chlorine samples are collected in the distribution system at the same time and place as total coliforms are sampled.

\*\* One sample for Chlorite at each of the following locations: near the first customer, at a location representative of the average residence time, and at a location reflecting maximum residence time of the water in the distribution system.

**Lead and Copper Monitoring Schedule**

Triennial			System size (number of people served)	Number of sites (reduced monitoring)
Sampling Period		Report is due to your district office no later than		
Start	End			
06/01/2006	09/30/2006	10/10/06	841	10

The dates and number of samples noted above supercede any previous schedule received from this agency. Copies of EPA Forms 5105, 5106, and 5107 are available on our web site at <http://www.epa.state.oh.us/ddagw/drinkforms.htm> or your district office to use for your next report. If your Lead and Copper monitoring does exceed an action level or if you have any other questions, please contact your district representative at Southeast District Office at (740) 385-8501

**2006 CHEMICAL MONITORING DISTRIBUTION SCHEDULE**

PWS ID: 6100203 PWS Name: Noble Water Company

Community Purchased Surface Water POPULATION: 810

Effective Date: 1/1/06

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district representative at Southeast District Office at (740) 385-8501 to review additional monitoring for total coliform, minimum requirements for chemical analysis for your monthly operating reports, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals (Code)</b>	<b>Monitoring Requirements</b>	<b>Sample Date</b>
Total Chlorine (1000)	Sample in the distribution system *	
Haloacetic Acids, five (HAA5)	1 Sample each quarter (Jan-Mar, Apr-Jun, Jul-Sep, Oct-Dec)	
Total Trihalomethanes (TTHM)	1 Sample each quarter (Jan-Mar, Apr-Jun, Jul-Sep, Oct-Dec)	
Chlorite (1009)	Not Required	

**Disinfectants and Disinfection Byproducts Sampling Information**

TTHM and HAA5 sample(s) should be collected from point(s) in the distribution system where the water age is the oldest. Use the MR00# as the sample monitoring point. If your system is also required to collect TTHM and HAA5 samples from other locations in your distribution system, use the appropriate RD00# as the sample monitoring point. Any questions concerning this schedule or the Disinfectants and Disinfection Byproducts Rule can be directed to Todd Kelleher of the Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

Multiple wells drawing water from a single aquifer may be considered one treatment plant for determining the number of TTHM and HAA5 samples required, with approval from Ohio EPA.

\* Total chlorine samples are collected in the distribution system at the same time and place as total coliforms are sampled.

\*\* One sample for Chlorite at each of the following locations: near the first customer, at a location representative of the average residence time, and at a location reflecting maximum residence time of the water in the distribution system.

**Lead and Copper Tap Schedule**

**Routine Lead and Copper Tap Monitoring Not Required**

**If a lead or copper action level has been exceeded, additional sampling may be required.**

**2006 CHEMICAL MONITORING DISTRIBUTION SCHEDULE**

PWS ID: 6100303 PWS Name: Pure Water Corporation  
Community Purchased Surface Water POPULATION: 1989  
Effective Date: 1/1/06

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district representative at Southeast District Office at (740) 385-8501 to review additional monitoring for total coliform, minimum requirements for chemical analysis for your monthly operating reports, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals (Code)</b>	<b>Monitoring Requirements</b>	<b>Sample Date</b>
Total Chlorine (1000)	Sample in the distribution system *	
Haloacetic Acids, five (HAA5)	1 Sample each quarter (Jan-Mar, Apr-Jun, Jul-Sep, Oct-Dec)	
Total Trihalomethanes (TTHM)	1 Sample each quarter (Jan-Mar, Apr-Jun, Jul-Sep, Oct-Dec)	
Chlorite (1009)	Not Required	

**Disinfectants and Disinfection Byproducts Sampling Information**

TTHM and HAA5 sample(s) should be collected from point(s) in the distribution system where the water age is the oldest. Use the MR00# as the sample monitoring point. If your system is also required to collect TTHM and HAA5 samples from other locations in your distribution system, use the appropriate RD00# as the sample monitoring point. Any questions concerning this schedule or the Disinfectants and Disinfection Byproducts Rule can be directed to Todd Kelleher of the Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

Multiple wells drawing water from a single aquifer may be considered one treatment plant for determining the number of TTHM and HAA5 samples required, with approval from Ohio EPA.

\* Total chlorine samples are collected in the distribution system at the same time and place as total coliforms are sampled.

\*\* One sample for Chlorite at each of the following locations: near the first customer, at a location representative of the average residence time, and at a location reflecting maximum residence time of the water in the distribution system.

**Lead and Copper Tap Schedule**

**Routine Lead and Copper Tap Monitoring Not Required**

**If a lead or copper action level has been exceeded, additional sampling may be required.**

**2006 CHEMICAL MONITORING DISTRIBUTION SCHEDULE**

PWS ID: 6100403 PWS Name: Pure Water System #2 PWS

Community Purchased Surface Water POPULATION: 279

Effective Date: 1/1/06

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district representative at Southeast District Office at (740) 385-8501 to review additional monitoring for total coliform, minimum requirements for chemical analysis for your monthly operating reports, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals (Code)</b>	<b>Monitoring Requirements</b>	<b>Sample Date</b>
Total Chlorine (1000)	Sample in the distribution system *	
Haloacetic Acids, five (HAA5)	1 Sample each quarter (Jan-Mar, Apr-Jun, Jul-Sep, Oct-Dec)	
Total Trihalomethanes (TTHM)	1 Sample each quarter (Jan-Mar, Apr-Jun, Jul-Sep, Oct-Dec)	
Chlorite (1009)	Not Required	

**Disinfectants and Disinfection Byproducts Sampling Information**

TTHM and HAA5 sample(s) should be collected from point(s) in the distribution system where the water age is the oldest. Use the MR00# as the sample monitoring point. If your system is also required to collect TTHM and HAA5 samples from other locations in your distribution system, use the appropriate RD00# as the sample monitoring point. Any questions concerning this schedule or the Disinfectants and Disinfection Byproducts Rule can be directed to Todd Kelleher of the Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

Multiple wells drawing water from a single aquifer may be considered one treatment plant for determining the number of TTHM and HAA5 samples required, with approval from Ohio EPA.

\* Total chlorine samples are collected in the distribution system at the same time and place as total coliforms are sampled.

\*\* One sample for Chlorite at each of the following locations: near the first customer, at a location representative of the average residence time, and at a location reflecting maximum residence time of the water in the distribution system.

**Lead and Copper Tap Schedule**

**Routine Lead and Copper Tap Monitoring Not Required**

**If a lead or copper action level has been exceeded, additional sampling may be required.**